

VRE - 2 poles		
Description	Old part-number	New part-number
2VRE15 170A	V02-02	B22-B0
2VRE15 170V	V02-01	B22-B1
2VRE15 200A	Z21-08	B22-B2
2VRE15 200V	Z21-09	B22-B3
2VRE25 250A	Z21-10	B22-B4
2VRE25 250V	Z21-11	B22-B5
2VRE45 300A	P04-66	B22-B6
2VRE45 300V	P04-67	B22-B7

VRE - 4 poles		
Description	Old part-number	New part-number
4VRE15 170A	V01-02	B22-B8
4VRE15 170V	V01-03	B22-B9
4VRE15 200A	P04-10	B22-C0
4VRE15 200V	P04-11	B22-C1
4VRE25 250A	P04-18	B22-C2
4VRE25 250V	P04-19	B22-C3
4VRE35 300A	P04-26	B22-C4
4VRE35 300V	P04-27	B22-C5
4VRE45 350A	P04-34	B22-C6
4VRE45 350V	P04-35	B22-C7
4VRE45 400A	P04-42	B22-C8
4VRE45 400V	P04-43	B22-C9

VGR - 2 poles		
Description	Old part-number	New part-number
2VGR15 200A	Z21-12	B22-D0
2VGR15 200V	Z21-13	B22-D4
2VGR25 250A	Z21-14	B22-D8
2VGR25 250V	Z21-15	B22-E2
2VGR45 300A	P04-68	B22-E6
2VGR45 300V	P04-69	B22-F0

VGR - 4 poles		
Description	Old part-number	New part-number
4VGR15 200A	P04-12	B22-F4
4VGR15 200V	P04-13	B22-F8
4VGR25 250A	P04-20	B22-G2
4VGR25 250V	P04-21	B22-G6
4VGR35 300A	P04-28	B22-H0
4VGR35 300V	P04-29	B22-H4
4VGR45 350A	P04-36	B22-H8
4VGR45 350V	P04-37	B22-I2
4VGR45 400A	P04-44	B22-I6
4VGR45 400V	P04-45	B22-J0

VPR - 2 poles		
Description	Old part-number	New part-number
2VPR15 200A	Z21-16	B22-D1
2VPR15 200V	Z21-17	B22-D5
2VPR25 250A	Z21-18	B22-D9
2VPR25 250V	Z21-19	B22-E3
2VPR45 300A	Q09-34	B22-E7
2VPR45 300V	Q09-35	B22-F1

VPR - 4 poles		
Description	Old part-number	New part-number
4VPR15 200A	Q09-20	B22-F5
4VPR15 200V	Q09-21	B22-F9
4VPR25 250A	Q09-22	B22-G3
4VPR25 250V	Q09-23	B22-G7
4VPR35 300A	Q09-24	B22-H1
4VPR35 300V	Q09-25	B22-H5
4VPR45 350A	Q09-26	B22-H9
4VPR45 350V	Q09-27	B22-I3
4VPR45 400A	Q09-28	B22-I7
4VPR45 400V	Q09-29	B22-J1

VGV - 2 poles		
Description	Old part-number	New part-number
2VGV15 200A	Z21-20	B22-D2
2VGV15 200V	Z21-21	B22-D6
2VGV25 250A	Z21-22	B22-E0
2VGV25 250V	Z21-23	B22-E4
2VGV45 300A	P04-70	B22-E8
2VGV45 300V	P04-71	B22-F2

VGV - 4 poles		
Description	Old part-number	New part-number
4VGV15 200A	P04-14	B22-F6
4VGV15 200V	P04-15	B22-G0
4VGV25 250A	P04-22	B22-G4
4VGV25 250V	P04-23	B22-G8
4VGV35 300A	P04-30	B22-H2
4VGV35 300V	P04-31	B22-H6
4VGV45 350A	P04-38	B22-I0
4VGV45 350V	P04-39	B22-I4
4VGV45 400A	P04-46	B22-I8
4VGV45 400V	P04-47	B22-J2

VGC - 2 poles		
Description	Old part-number	New part-number
2VGC15 200A	Z21-24	B22-D3
2VGC15 200V	Z21-25	B22-D7
2VGC25 250A	Z21-26	B22-E1
2VGC25 250V	Z21-27	B22-E5
2VGC45 300A	P04-72	B22-E9
2VGC45 300V	P04-73	B22-F3

VGC - 4 poles		
Description	Old part-number	New part-number
4VGC15 200A	P04-16	B22-F7
4VGC15 200V	P04-17	B22-G1
4VGC25 250A	P04-24	B22-G5
4VGC25 250V	P04-25	B22-G9
4VGC35 300A	P04-32	B22-H3
4VGC35 300V	P04-33	B22-H7
4VGC45 350A	P04-40	B22-I1
4VGC45 350V	P04-41	B22-I5
4VGC45 400A	P04-48	B22-I9
4VGC45 400V	P04-49	B22-J3